



selva wall

SV PSC18, SV PSC12, SV PSC6, SV PSCD12, SV PSCD6,
installation manual






bejot:

people




additional tools




parts




1



2




attached




* - not added for assembly,
parts suitable for the ground



1





2




3




4




5




6




7





8




9




10



11




12




13

dimensions


SV PSC18




SV PSC12




SV PSC6



SV PSCD12



SV PSCD6



Bejot Sp. z o. o.

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznań, POLAND

tel.: +48 (61) 281 22 25, e-mail: biuro@bejot.eu

www.bejot.eu

edition 11/2021