

















Yaasa Desk Pro Assembly Guide






12A



13



12B

